

SOLID PERFUME

PHASE	Ingredient name	INCI name	V1	V2
			%	%
A	Rice Bran Wax	Oryza Sativa (Rice) Bran Wax	15	15
	Kester Wax K70P	C18-38 Alkyl Hydroxystearoyl Stearate	5	-
	Kester Wax K80 EU	C20-40 Alkyl Stearate	-	5
	Fruit Peel Wax	Rhus Succedanea Fruit Wax / Rhus Verniciflua Peel Wax	10	10
	Kester Wax K24	Lauryl Laurate	10	10
	Neoderm TCC	Caprylic/Capric Triglycerides	27	27
B	Neoderm TCC	Caprylic/Capric Triglycerides	27	27
	Fragrance	Parfum oil	5	5
	Tocopheryl Acetate	Tocopheryl Acetate	1	1

Method

- Heat PHASE A to 85 °C and mix during 10 min, stop heating
- Add PHASE B to PHASE A when temperature cools down and mix well
- Pour the product into desired packaging at 55 - 60 °C

